

## SaarFloor Rubber Flooring

## SaarFloor BERNSTEIN

## SaarFloor DIAMANT

## SaarFloor NOPPE

### 1. GENERAL INFORMATION

The processing guidelines of the adhesive manufacturers and instructions of the hazardous substance's regulation are must be observed. The floor covering must be laid in accordance with the technical regulations of DIN 18 365 "Floor covering work" take place. The flatness tolerances according to DIN 18 202, "Tolerances in building construction" according to part 5, Line 4, (Example: Nominal dimension range of 10 cm may a deviation from the plane of 1 mm is not allowed), trowel strokes are to be avoided. At heavy duty areas (use of lift trucks) the substructure, i.e. screed and filler, must be adapted to this type of use.

The floor covering material must be checked for damage, defects, etc. Notifications of defects or replacement deliveries are only possible if the floor has not been laid.

Sheets and tiles are always in the same arrow direction (marking on the back of the covering) to installed.

The processing instructions of the adhesive manufacturers must be observed.

### 2. SaarFloor DIAMANT – Sheets

The seam is always cut before the adhesive is applied. The edges of the sheets should overlap by approx. 2 – 3 cm. With ruler guide and a trapezoidal blade or suitable cutter the top covering and cut the one below almost completely. The lower covering strip can be used for single layer. Remove the coverings downwards.

Fold the sheets back halfway and apply the adhesive in the right quantity with a toothed spatula, as a rule apply A2 (follow manufacturer's instructions). The required flash-off time depends on the temperature, the humidity and absorbency of the air of the subfloor resistant in dependence. A wetting of the underside of the flooring over the entire surface with adhesive must be observed.

When laying, insert the edges of the sheets without tension.

Wrap the second half of the sheet and apply adhesive. Double adhesive application in the middle of the sheet (cover edge) should be avoided.

After bonding the flooring is then rolled over the entire surface or rub it in.

The flooring must be protected during installation and the setting time of the adhesive from temperature changes e.g. by solar radiation. Initial care or wet cleaning may only be carried out after setting of the adhesive is carried out after approx. 48 hours.

The joints of the covering seams may not be grouted before 24 hours after installation.

### 3. SaarFloor BERNSTEIN, NOPPE – Tiles

Lay out tiles unglued in the direction of the arrows in the whole room. Cut to size door connections, pipe penetrations and edge tiles. In addition, the floor covering can so acclimatise to the underfloor temperature.

Fold over the row of tiles and apply the adhesive. The horizontal tile serves as a stop for the tiles to be laid. An uneven tile pattern or tile misalignment is thus avoided. The freshly glued floor covering must not be subjected to point loads otherwise crushing of the adhesive may occur.

Place tiles in the wet adhesive bed. Press on highlighted bend corners and edges (any cavities or similar must be weighted down until the material has set of the adhesive).

Adhesive residues on the flooring surface must be removed immediately (for dispersion adhesives with damp sponge or cloth, in case of reaction resin with suitable liquid wax).

The flooring must be protected during installation and the setting time of the adhesive from temperature changes e.g. by solar radiation. Initial care or wet cleaning may only be carried out after setting of the adhesive is carried out after approx. 48 hours.

**For further guidance contact objectflor Customer Technical Support.**

**Please note our current recommended adhesives and our maintenance instructions.**